IRIDIUM GMDSS DISTRESS ALERT

product sheet



DISTRESS ALERT - HOW DOES IT WORK?

In case of DISTRESS:

- Press and hold the DISTRESS button for three seconds to activate Distress Alert
- Distress Alert sending...
- Distress Alert delivered (incl. vessel's position & identification)
- Terminal automatically establish a Distress Call to RCC (Rescue Coordination Centre)
- Distress Call established between vessel and RCC within 30 seconds








product sheet

SOLAS GMDSS REQUIREMENTS FOR CARGO VESSELS OVER 300 GT AND FOR ALL PASSENGER VESSELS OPERATING IN INTERNATIONAL WATERS.

Sea Area	VHF DSC 1	VHF DSC 2	MF DSC	MF/HF DSC incl. HF telex	SES 1 Iridium or Sat-C	SES 2 Iridium or Sat-C
A1	x					
A2	X		Х			
A3	Х	Х	Х	Х	X	
A3 Sat	Х	х	Х		X	X
A4	х	х	Х	хх	х	



All areas: + Navtex, SART, EPIRB & handheld VHF



Lars Thrane A/S Skovlytoften 33 DK-2840 Holte, Denmark

Phone: +45 88 30 10 00 Fax: +45 88 30 10 09

Email: sales@thrane.eu CVR DK-36042443 www.thrane.eu